


Upgrading the firmware


MEMO


Check the firmware version when the unit is starting up. Version 1.00 is shown as "1/00," for example.





1. Copy the firmware upgrade file to the microSD card.

- The latest version of the firmware can be downloaded from our web site (www.zoom.co.jp).

2. While pressing , slide the power switch to start the unit in version upgrade mode. The version currently used by the unit and the upgrade version are shown on the screen alternately.



3. If the version upgrade shown is the one desired, press the  button to open a confirmation screen. Press  again to start the upgrade.